# **Technical Data Sheet (TDS)**

NOROX<sup>®</sup>411 Polymerisation (PO)



# NOROX®411

tert-Amyl peroxy-2-ethylhexanoate CAS#686-31-7 Colourless liquid

#### Structural Formula

## **Description**

Colourless, mobile liquid, consisting of technically pure *tert*-amyl peroxy-2-ethylhexanoate. This branched, aliphatic perester is used as a radical initiator in the polymerisation of monomers, *e.g.* ethylene, styrene and (meth)acrylates.

### **Technical Data**

Appearance	colourless liquid
Assay	ca. 98 % w/w
Active oxygen (AO)	ca. 6.81 % w/w
Density at 20 °C	ca. 0.9 g/cm <sup>3</sup>
Viscosity at 20 °C	ca. 4.3 mPa·s
Refractive index at 20 °C	ca. 1.433
Flash point	ca. 59 °C
Vapour pressure at 25 °C	< 0.1 mbar
Critical temperature (SADT)	ca. 35 °C
Cold storage stability	below -25 °C
Recommended storage temperature	below 10 °C
Storage stability as from date of delivery	3 months

### **Standard Packaging**

1 gallon bottle5 gallon Unitainer

#### Half-life Data

10 h / 1 h / 1 min (benzene, 0.1 mol/L) 72 °C / 91 °C / 130 °C

# **Technical Data Sheet (TDS)**

NOROX®411 Polymerisation (PO)



#### **Application**

#### ETHYLENE:

Initiator for the high-pressure polymerisation of ethylene in combination with other peroxides of different thermal stability.

Temperature range: 160 - 210 °C

Particular advantages: liquid, readily miscible with high-boiling aliphatics, highly efficient.

#### STYRENE:

Initiator for the polymerisation in bulk, solution, or suspension.

Temperature range: 80 - 110 °C

Dosage: 0.1 - 0.5 %

Particular advantages: no plasticiser, liquid and therefore easy to dose, high

activity

A low residual monomer content can be achieved in combination with other, thermally more stable peroxides.

#### OTHER MONOMERS:

Initiator for the polymerisation of (meth-)acrylates and allyl-monomers.

Temperature range: 80 - 120 °C

Dosage: 0.1 - 1 %

In combination with thermally more stable peroxides the residual monomer content in the polymer can be reduced.

#### **Decomposition Products**

Possible detectable decomposition products: acetone, *tert*-amyl alcohol, ethyl *tert*-amyl ether

#### Storage

Avoid any source of heat, light, humidity and protect the product from impurities. Keep within safe temperature limits.

#### Disclaimer:

The information contained herein and all further technical advice that may be provided by United Initiators reflects our current knowledge and experience based on our internal research and development as to our products and applications. United Initiators does not make any warranties about the information provided as to specific properties of products described their suitability for a particular application and representing complete instructions for use. Additionally, United Initiators does not make any warranties in respect of product and shelf-life properties. We are not legally responsible and liable for the use of any information provided, including with regard to existing third-party intellectual property rights, especially patent rights. We reserve the right to make any changes according to technological progress or further developments.

Application and usage of our products based on our technical advice is out of our control, strictly at your own risk and is the sole responsibility of the user. The user is not released from the obligation to conduct careful inspection and testing of incoming products in order to verify their suitability for the intended application.

United Initiators Europe T: +49 89 74422 237 F: +49 89 74422 6237

United Initiators Nafta
T: +1 800 231 2702
F: +1 440 323 0898
cs-initiators.nafta@united-in.com

United Initiators China T: +86 20 6131 1370 F: +86 139 2503 8952 cs-initiators.cn@united-in.com United Initiators

Australia
T: +61 2 9316 0046
F: +61 2 9316 0034
cs-initiators.au@united-in.co